


SIPROMAC

ANCIEN  
MANUEL  
EDITION  
OCT. 1990



MODELE

EQUIPEMENT - ALIMENTATION



FOOD PROCESSING EQUIPMENT

SIPROMAC INC.

VACUUM PACKAGING CHAMBER

MODEL 600

GENERAL TABLE OF CONTENTS:

I OPERATION INSTRUCTIONS

II MECHANICAL DRAWINGS

- A- Front view general assembly drawing
- B- Rear view general assembly drawing
- C- Cover assembly drawing
- D- Cover assembly drawing (Bi-active seal bar option)
- E- Cover assembly drawing (Mechanical bag cut option)
- F- Seal bar assembly
- G- Seal bar assembly (Bi-active seal option)

III ELECTRICAL DRAWINGS

- A- Wiring diagram 15 pins
- B- Electrical drawing low voltage
- C- Electrical drawing high voltage (600-1 Ø)
- D- Electrical drawing high voltage (600-3 Ø)

IV PNEUMATIC DRAWINGS

- A- Pneumatic drawing
- B- Pneumatic drawing (option air regulator)

**SIPROMAC INC.**

2355, CANADIEN  
DRUMMONDVILLE, QUÉBEC, CANADA  
J2B 8A9  
TÉL.: (819) 474-1212  
FAX: (819) 474-3994



SIPROMAC INC

VACUUM PACKAGING MACHINES

OPERATION INSTRUCTION

TABLE OF CONTENTS:

PAGE:

1. Setting up the machine	1
2. Electrical connection	1
3. Operation	2
3.1 Working principals	2
3.2 Special packaging	3
3.2.1 Gas flushing	3
3.2.2 Up and down seal	3
3.3 Setting of digital controls	4
3.4 Daily cleaning	5
4. Trouble shooting	5
4.1 Failure during a packaging cycle	5
4.2 Insufficient vacuum	5
4.2.1 Leakage in the bag	5
4.2.2 No leakage in the bag	6
4.2.3 Insufficient vacuum in chamber	6
4.3 Faulty seal	7
4.3.1 Insufficient seal	7
4.3.2 No seal	7
4.3.3 Permanent sealing current	7
4.3.4 Seal does not stick	8
4.4 Fault in the valves	8
4.5 Control Board Failure	8
5. Regular maintenance	9
Annexe: Electrical schematic.	

**SIPROMAC INC.**

2355, CANADIEN  
DRUMMONDVILLE, QUÉBEC, CANADA  
J2B 8A9  
TEL.: (819) 474-1222



SIPROMAC INC.

VACUUM PACKAGING MACHINES

OPERATION INSTRUCTIONS

1. SETTING UP THE MACHINE:

Before choosing the site for the machine, please consider that you will also need room for packaged and non-packaged products apart from the space needed for the machine itself.

Keep in mind that the machine must not be set up upon uneven ground. Especially with mobile models, the weight of the pump might then cause warping of the chamber. Then the lid will not fit closely upon the chamber and this gives a lot of avoidable troubles at operation.

Before starting to work, check at the oil view glass of the pump, whether there is a sufficient quantity of oil in the pump. Never use oil other than recommended by the producer. Never exceed maximum quantity of oil indicated, when adding or changing oil.

Due to the oil viscosity, the machine is hard to start when temperatures are very low. Therefore the pump ought to be set up in a room with an air temperature of at least 50°F (+10°C). On the other hand, there must be free access of air to the pump to allow for cooling so that operation temperature of 160°F (70°C) is not exceeded.

2. ELECTRICAL CONNECTION:

Electrical connections must be made by qualified personnel. This person must make sure that the electrical entries corresponds to the proper voltage and amperage of the machine.


All vacuum machines have an electrical schematic in the electrical casing.



### 3.3 Setting of digital controls

## INSTRUCTIONS

Control panel



To turn on: Press the "Power On" key.

To turn off: Press the "Power Off" key.

To program the vacuum cycle:

1. Press the "V" key for about 3 seconds. The display will flash.
2. Indicate your desired timing by pressing on "X10" and/or "X1".
3. Press one more time on the "V" key. The display stays on.

To program the gas cycle:

1. Press the "G" key. The display will flash.
2. Indicate your desired timing by pressing on "X10" and/or "X1".
3. Press again on "G". The display stays on.

To program the sealing cycle:

1. Press the "S" key. The display will flash.
2. Indicate your desired timing by pressing on "X10" and/or "X1".
3. Press again on "S". The display stays on.

The micro-processor will memorize the last program you entered. The system functions with a 5 volts Cadium Nickel battery which lasts approximately 3 years and recharges automatically if your machine remains plugged in. You may notice, during the first few days of use, that your micro-processor does not keep your program in memory, it is absolutely normal due to the fact that your battery is not fully charged.

#### BASIC PROGRAM TO MODIFY ACCORDING TO THE PRODUCTS

MACHINE	"V"	* "G"	"S"
VAC - 350	20 sec.	AS NEEDED	1 - 3 sec.
VAC - 450	22 sec.	AS NEEDED	1 - 5 sec.
VAC - 550	25 sec.	AS NEEDED	1 - 5 sec.
VAC - 600	25 sec.	AS NEEDED	1 - 5 sec.
VAC - 650	27 sec.	AS NEEDED	1 - 7 sec.

modify your program, increase by "1" as desired by pressing on the "X1" key.  
 \* If you do not use the gas option you have to program "00".

"V" --- indicated in seconds

"G" --- indicated in seconds

"S" --- indicated in seconds and 10th of a second.

**Warning:** Do not increase the sealing time too much to prevent deteriorating the tefflons.

### CON'T 3.3 SETTING OF DIGITAL CONTROLS

#### NOTE:

Pressing the "V" key during the vacuum cycle will stop the vacuum cycle and go to the next step (gas or sealing). This is especially useful to package liquids.

#### 3.4 Daily cleaning:

For hygienic cleanliness, it is imperative to clean chamber and spacers daily. Also clean upper rim of the chamber as well as the lid rubber to assure tight seat of the lid. Regular application of talcum powder will increase working life of the lid rubber.

Check oil of the pump weekly and add if necessary. Only use oil types recommended by the producer (see pump brochure).

Check vacuum hose for damage regularly, will save you a lot of avoidable trouble with machine breakdown.

#### WARNING

ALL ELECTRICAL WORK DESCRIBED IN THIS BROCHURE SHOULD BE DONE BY A QUALIFIED AND AUTHORIZED TECHNICIAN.

#### 4 TROUBLE SHOOTING:

##### 4.1 Failure during a packaging cycle:

The lid is closed and cycle fails to start or stops immediately after having started:

Micro switch is actuated too late, re-set the micro switch.

Fault in supply of electricity to the timing control (Power on light does not go on):

Check input voltage at transformer (Faulty contact in wires)

Check secondary voltage of transformer ( Approx. 24 Volt AC)

Check fuse

If none of these applies; exchange electronic card.

#### 4.2 Insufficient vacuum;

##### 4.2.1 Leakage in the bag;

Most frequently, insufficient vacuum in bags is due to leakage in bag and not to any fault of the machine.

Pin-point leak for which there is no obvious explanation. Faulty bag material.

Pin-point leak caused by sharp edge of the product. (Bone, etc.) use bone-guard or thicker film.

Rent of tear in bag by careless handling (Sharp edge on filling table, damage made by retailer or customer).

Leakage in lateral or bottom seal, complain at supplier's.

##### 4.2.2 No leakage in the bag;

Bag is too large, therefore the residue air remains visible (There is residue air of 0.4% of bag volume in each bag). Use bags of suitable size.

Evacuation time is too short:

Pressure bar is jammed and closes opening of bag during evacuation.

##### 4.2.3 Insufficient vacuum in chamber;

If troubles described under 4.2.1 and 4.2.2 do not apply, there is something wrong with evacuation. To find the leakage quickly, check for leak with precision vacuummeter, going back step by step from the chamber to the pump.

At the chamber (measuring point at block valve) at maximum time of evacuation. If more than 6 torr, proceed to.

Directly at the pump, if more than 3 torr: Have pump serviced at pump supplier's workshop. If pressure at pump is all right:

Reconnect hoses to pump and measure again.

After the vacuum hose.

After the block valve.

With double chamber machine, after the air joint in lid.



.../7

Con't 4.2.3 Insufficient vacuum in chamber,

When proceeding this way, starting from pump, loss of pressure per step must not exceed 0.5 to 1 torr.

Warning: Keep in mind; absolute tightness of hoses and connections of measuring equipment.

Most frequent points of leakage: Lid gasket, damaged vacuum hose and loose hose clamps.

4.3 Faulty seal;

4.3.1 Insufficient seal;

Damaged teflon or silicone rubber.

Sealing pressure too low, membrane hose leaking or pressure bar jammed.

Leakers in seal (no homogenous sealline): heating wire mechanically damaged (knick by some blow, etc.) or silicone rubber uneven.

4.3.2 No seal;

Sealing wire burnt.

Faulty contact in sealing circuit

Sealing transformer burnt through.

Contactor does not work.

4.3.3 Permanent sealing current;

Contactor is jammed check sealing transformer for damage through overload.

.../8

4.3.4 Seal does not stick;

Insufficient layer of polyethylene (inferior quality of bags)

Seal area extremely contaminated by fat or meat juice. Use filling aid.

Sealing temperature is too low (when using very thick films)

Warning: Do not increase sealing time more than really necessary; higher temperature will reduce working life of teflon and silicone rubber.

4.4 Fault in the valves;

Vacuum or air valve does not open.

Check whether there is voltage on the portaining magnetic valves during their period of operation. If there is no voltage a wire is broken or the timing card is damaged.

If there is current, check change of vacuum and atmospheric pressure on hose from magnetic valve to block valve with the tip of your finger. If this is correct, the fault is in the block valve.

Lid does not open at the end of the cycle; air enters, but there is still a residue vacuum of 20 - 40% in the chamber. Vacuum valve does not close.

PROBLEM	POSSIBLE CAUSE	
1 No display	1.1 Programmin error.	Press on/off switch or membrane switch
	1.2 No current coming to PC board.	Check fuses Check voltage between pins # <u>6</u> and # <u>13</u> on "D" connector, the reading should be approx. 9 AC volts. (transformer or wiring defect)
	1.3 On/off key defective	Disconnect flat cable between PC board and membrane switch and jump pins 1 and 2 or 7 and 8 using a screw-driver
	1.4 Defective PC board	Replace PC board
2 Two digits continously flashes on "V", "G" or "S"	2.1 Programming error	Press corresponding "V", "G", or "S" key
	2.2 Defective membrane switch	Replace membrane switch
	2.3 Defective PC board	Replace PC board
3 All of the display continously flashes	3.1 Cover Switch remains closed	Check cover switch or continuity between pins # 8 and # 15 on PC board connector (see dwg #006-0029)
	3.2 Defective PC board	Replace



8 Machine "recycling"  
or cycle "Re-start  
continuously.

8.1 Poorly adjusted cover  
switch

Adjust

8.2 Defective PC board

Replace

9 Double chamber:  
Vacuum sealing or  
atmosphere is not  
done on one side only


9.1 Defective relay or  
connection

Replace the 4FDT  
(in electrical box)  
This relay switch  
functions from one  
side to the other.  
(the PC board is good  
because there is one  
output which control's  
both sides)

9.2 Defective contactor  
or valve

Test voltage on coil

21	1073	SEAL BAR	4
22	001-0434	SEAL BAR SUPPORT	2
23	9100-105	SELF STICK TEFLON	4
24	051-0150	FLAT HEAD SCREW 10-24 X 3"	4
19	Ø 15-015	ELEMENT	2
18		COVER GASKET	1
17	076-	O-RING 3/16" x 5/16"	5
16	056-0014	HOLD DOWN CLIP	2
15	051-0760	FLAT WASHER 5/16"	4
14	051-0150	BOLT # 10-24 x 1 1/2"	1
13	051-0600	NUT 5/16" - 18	4
12	051-0310	BOLT 5/16" - 18 x 1 1/2"	4



11	051-0178	SET SCREW 1/4-20 x 5/16"	4
10	051-0740	FLAT WASHER 1/4"	5
9	051-0510	ACORN NUT #10-24	5
8	002-0077	SEAL BAR SPACER	4
7	001-1187	CROSS BEAM COVER	1
6	005-0287	CROSS BEAM ASSEMBLY	1
ITEM	#	PIECE	DESCRIPTION

5	001-1186	BEAM REINF. PLATE	1	QTE
4	002-0062	CONNECTER	4	
3	051-0550	NUT 8-32	8	
2	005-0286	GUIDE SUPPORT ASSEMBLY	1	
1	002-0254	COVER		
ITEM	#	PIECE	DESCRIPTION	QTE

MOM MACHINE		ITEM		#		PIECE		DESCRIPTION		QTE	
VACUUM 600				TOLERANCE							
				A 1.5							
				B 1.05							
				C 1.005							
				D 1.005							
				E 1.005							
				F 1.005							
				G 1.005							
				H 1.005							
				I 1.005							
				J 1.005							
				K 1.005							
				L 1.005							
				M 1.005							
				N 1.005							
				O 1.005							
				P 1.005							
				Q 1.005							
				R 1.005							
				S 1.005							
				T 1.005							
				U 1.005							
				V 1.005							
				W 1.005							
				X 1.005							
				Y 1.005							
				Z 1.005							
				AA 1.005							
				AB 1.005							
				AC 1.005							
				AD 1.005							
				AE 1.005							
				AF 1.005							
				AG 1.005							
				AH 1.005							
				AI 1.005							
				AJ 1.005							
				AK 1.005							
				AL 1.005							
				AM 1.005							
				AN 1.005							
				AO 1.005							
				AP 1.005							
				AQ 1.005							
				AR 1.005							
				AS 1.005							
				AT 1.005							
				AU 1.005							
				AV 1.005							
				AW 1.005							
				AX 1.005							
				AY 1.005							
				AZ 1.005							
				BA 1.005							
				BB 1.005							
				BC 1.005							
				BD 1.005							
				BE 1.005							
				BF 1.005							
				BG 1.005							
				BH 1.005							
				BI 1.005							
				BJ 1.005							
				BK 1.005							
				BL 1.005							
				BM 1.005							
				BN 1.005							
				BO 1.005							
				BP 1.005							
				BQ 1.005							
				BR 1.005							
				BS 1.005							
				BT 1.005							
				BU 1.005							
				BV 1.005							
				BW 1.005							
				BX 1.005							
				BY 1.005							
				BZ 1.005							
				CA 1.005							
				CB 1.005							
				CC 1.005							
				CD 1.005							
				CE 1.005							
				CF 1.005							
				CG 1.005							
				CH 1.005							
				CI 1.005							
				CJ 1.005							
				CK 1.005							
				CL 1.005							
				CM 1.005							
				CN 1.005							
				CO 1.005							
				CP 1.005							
				CQ 1.005							
				CR 1.005							
				CS 1.005							
				CT 1.005							
				CU 1.005							
				CV 1.005							
				CW 1.005							
				CX 1.005							
				CY 1.005							
				CZ 1.005							
				DA 1.005							
				DB 1.005							
				DC 1.005							
				DD 1.005							
				DE 1.005							
				DF 1.005							
				DG 1.005							
				DH 1.005							
				DI 1.005							
				DJ 1.005							
				DK 1.005							
				DL 1.005							
				DM 1.005							
				DN 1.005							
				DO 1.005							
				DP 1.005							
				DQ 1.005							
				DR 1.005							
				DS 1.005							
				DT 1.005							
				DU 1.005							
				DV 1.005							
				DW 1.005							
				DX 1.005							
				DY 1.005							
				DZ 1.005							
				EA 1.005							
				EB 1.005							
				EC 1.005							
				ED 1.005							
				EE 1.005							
				EF 1.005							
				EG 1.005							
				EH 1.005							
				EI 1.005							
				EJ 1.005							
				EK 1.005							
				EL 1.005							
				EM 1.005							
				EN 1.005							
				EO 1.005							
				EP 1.005							
				EQ 1.005							
				ER 1.005							
				ES 1.005							
				ET 1.005							
				EU 1.005							
				EV 1.005							
				EW 1.005							
				EX 1.005							
				EY 1.005							
				EZ 1.005							
				FA 1.005							
				FB 1.005							
				FC 1.005							
				FD 1.005							
				FE 1.005							
				FF 1.005							
				FG 1.005							
				FH 1.005							
				FI 1.005							
				FJ 1.005							
				FK 1.005							
				FL 1.005							
				FM 1.005							
				FN 1.005							
				FO 1.005							
				FP 1.005							
				FQ 1.005							
				FR 1.005							
				FS 1.005							
				FT 1.005							
				FU 1.005							
				FV 1.005							
				FW 1.005							
				FX 1.005							
				FY 1.005							
				FZ 1.005							
				GA 1.005							
				GB 1.005							
				GC 1.005							
				GD 1.005							
				GE 1.005							
				GF 1.005							
				GG 1.005							
				GH 1.005							
				GI 1.005							
				GJ 1.005							
				GK 1.005							
				GL 1.005							
				GM 1.005							
				GN 1.005							
				GO 1.005							
				GP 1.005							
				GQ 1.005							
				GR 1.005							
				GS 1.005							
				GT 1.005							
				GU 1.005							
				GV 1.005							
				GW 1.005							
				GX 1.005							
				GY 1.005							
				GZ 1.005							
				HA 1.005							
				HB 1.005							
				HC 1.005							
				HD 1.005							
				HE 1.005							
				HF 1.005							
				HG 1.005							
				HH 1.005							
				HI 1.005							
				HJ 1.005							
				HK 1.005							
				HL 1.005							
				HM 1.005							
				HN 1.005							
</											

.../9


## 5. Regular Maintenance:

### Routine controls to be made at regular intervals:


- Check teflon for wear.
- Check silicone rubber for burnt spots and smooth even position.
- Check pressure bar for jamming.
- Check lid sealing for damage and hardened spots.
- Clean upper chamber rim.
- Check switch-point of micro switch, adjust if necessary.
- Check evacuation hose for damage (Contraction of diameter abrasions).
- Check vacuum connections for tightness.
- Check oil in pump (oil level in view glass;  
Add if necessary. Regular exchange of oil - necessity indicated by change of colour).
- Check vacuum in chamber with precision vacuumeter.
- Check function of cycle with various settings of timers.

Sipromac Inc.  
2355, Canadien  
Drummondville. Québec  
Canada J2B 8A9  
(819) 474-1222  
Fax: (819) 474-3994






MECHANICAL DRAWING



41	005-0299	BIACTIVE SEAL COVER (001)	1
40	002-0298	CONNECTER WEIGHT SPACER	2
39	051-0740	FLAT WASHER 1/4"	2
38	002-0299	CENTER ARM BUSHING	2
37	056-0005	SPRING PIN 5/16" x 2"	2
36	056-0004	SPRING PIN 3/16" x 2"	2
35	002-0297	SURET LINDOR	1
34	056-0012	CUTTER PIN 1/8" x 1"	1
33	051-0740	FLAT WASHER 1/4"	1
32	FB-46-2	BRONZE BUSHING 1 3/8" x 1/2"	1
31	005-0290	COVER GUIDE ARM ASSEMBLY	1
30	051-0740	FLAT WASHER 1/4"	1
28	051-0581	NYLON LOCKWIT 1/4"-20	2
27	005-0163	GUIDE ARM PIVOT SHAFT	1
25	052-4220	BOLT # 8-30	3
24	001-0199	PIPE SUPPORT	3
23	-----	VACUUM PUMP 63"	1
22	051-0180	BOLT 1/4"-20 x 1 1/2"	2
21	001-0710	SWITCH SUPPORT	2
20	051-0580	NUT 1/4" - 20	1
19	056-0012	CUTTER PIN 1/8" x 1"	1
18	FB-46-2	BRONZE BUSHING 1 3/8" x 1/2"	1
17	002-0074	COVER ARM SPACER	1
16	005-0273	REC. BAG CUT COVER ASSEM.	1
15	005-0272	STANDARD COVER ASS.	1
14	005-0284	REAR PANEL ASSEMBLY	1
13	051-0250	BOLT 1/4" - 20 x 1 1/2"	2
12	004-0089	REAR ARM ASSEMBLY	1
11	002-0300	ARM BUSHING	1
10	051-0740	FLAT WASHER 1/4"	4
9	051-0581	NUT 1/4" - 20	2
8	002-0301	BODY ARM SPACER	1
7	051-0410	BOLT 3/8" - 16 x 2 3/4"	2
6	-----	CIRCLIP	1
5	001-1191	COVER WEIGHT SUPPORT	1
4	008-0277	CAMMER WEIGHT	1
3	002-0242	BOTTOM ARM BUSHING	1
2	005-0289	CAMMER WEIGHT SUPPORT AS	1
1	051-0620	NUT 3/8" - 16	2
ITEM	PIECE	DESCRIPTION	QTE




NON MACHINE		VACUUM 600		TOLERANCE 0.5 0.05 0.005	
NON PIECE		ASSEMBLY REAR VIEW		DATE : 90-08-23	
O.T.L.		E.C.H.		NO DESIGN	
MATERIEL		NE PAS MESUREUR		005-0275	
APPR.		ALAIN		DATE	
				DRUMMOND VILLE, QUEBEC, CANADA.	






40	051-0180	BOLT 1/4"-20 x 1/2"	3
39	051-0740	FLAT WASHER 1/4"	6
38	005-0035	ELECTRIC BOX ASSEMBLY	1
37	-----	GASKET 3/8 Ø	1
36	001-0137	COVER	1
35	051-0740	FLAT WASHER 1/4"	4
34	051-0180	BOLT 1/4"-20 x 1/2"	4
33	005-	CHAMBER ASSEMBLY	1
32	051-0580	NUT 1/4" - 20	4
31	005-0291	PC BOARD SUPPORT	1
30	-----	SIPROMAC TOUCH PAD	1
29	002-0074	COVER SPACER	1
28	005-	SPACER ASSEMBLY	1
27	002-0201	COVER ARM SPACER	1
25	051-0350	BOLT 3/8" -16 x 3/4"	1
24	051-0740	FLAT WASHER 1/4"	2
23	051-0581	NYLON LOCKNUT 1/4"-20	2
22	002-0300	ARM BUSHING	1
21	051-0250	BOLT 1/4" -20 x 1 1/2"	2
20	051-0740	FLAT WASHER 1/4"	2
19	051-001	BLACK PLASTIC KNOB	1
18	051-0780	FLAT WASHER 3/8"	1
17	004-0098	FRONT ARM ASSEMBLY	1
16	005-0127	CONTROL PANEL ASSEMBLY	1
15	051-0591	ACORN NUT 1/4" - 20	4
14	051-0740	FLAT WASHER 1/4"	4
13	051-0250	BOLT 1/4" -20 x 1 1/2"	4
12	051-0581	NYLON LOCKNUT 1/4"-20	4
11	051-0580	NUT 1/4"-20	8
10	005	BODY ASSEMBLY	1
9	051-0581	NYLON LOCKNUT 1/4"-20	16
8	002-0057	SEAL BAR GUIDE	8
7	0425	TUBE CLAMPS	16
6	008-	TUBE (GAS INJECTION)	2
5	005-	GAS INJECT. BAR	4
4	005-0273	MET. BAG CUT COVER AS	1
3	005-0272	COVER ASSEMBLY	1
2	005-0271	SEAL BAR ASSEMBLY	4
1	005-0270	SEAL BAR ASSEMBLY	4
ITEM # PIECE DESCRIPTION			QTY





NOM MACHINE VACUUM 600		TOLERANCE a : 5 b : 0.05 c : 0.005 ANGLE : 1°		
NOM PIECE ASSEMBLY FRONT VIEW				
QTL	1	ECU		
NE PAS MESURER ALAIN 90-08-23 NO DESSIN 005-0274				




ITEM	#	PIECE	DESCRIPTION	QTY
1	002-0063		SEAL BAR	4
1	008-0021		BAG CUT SEAL BAR (OPTION)	4
2	002-0031		CONNECTER	8
3	035 015		SEALING ELEMENT	8
3	035 015		SEALING ELEMENT (OPTION BAG CUT)	4
4	051-0178		HEX SOCKET SET SCREW	16
5	-----		BAG CUT WIRE (OPTION)	4
6	051-0140		FLAT SLOTTED SCREW #8-32 x 1 1/4"	8
7	051-0550		NUT # 8-32	8
8	9100 101		SELF STICK TEFLON TAPE	4
9				
10	005-022R		SEAL BAR SUPPORT ASSEMBLY	4
11				
12	051-0180		BOLT 1/4"-20 x 3/4"	16
13	051-0740		FLAT WASHER 1/4"	16
14	005-0148		BELLOWS ASSEMBLY	4



		DRUMMOND VILLE, QUEBEC, CANADA.	
TOLERANCE .005 : .005 .005 : .005 .005 : .005 ANGLE : f		DATE 90-07-24 DATE 90-08-10	
VACUUM 600 SEAL BAR ASSEMBLY		NE PAS MESURER	
QTY. 1 MATERIEL	ECH.	DESINE ALAIN APPR DAVE	NO DESSIN 005-0270




ITEM	#	PIECE	DESCRIPTION	QTY
30	051-0740	1	FLAT WASHER 1/4"	5
29	005-0288	1	GUIDE SUPPORT ASSEMBLY	1
28	076-	5	O-RING 3/16" x 5/16"	5
27	051-0740	1	WASHER 1/4"	1
26	051-0580	1	NUT 1/4" - 20	1
25	001-1188	2	SPACER	2
24	001-0778	2	SEAL BAR SUPPORT	2
23	051-0740	6	FLAT WASHER 1/4"	6
22	051-0580	6	NUT 1/4" - 20	6
21	-----	1	COVER GASKET 3/8" Ø	1
20	051-	6	SOCKET HEAD CAP SCREW 1-20 x 1 1/2"	6
19	051-0250	4	BOLT 1/4" - 20 x 1 1/2"	4
18	008-0276	2	RUBBER SEAL BAR	2
17	051-	6	FLAT HEAD SCREW #10-24 x 3 1/8	6
16	001-0093	2	RUBBER SEAL HOLDER	2
15	002-0198	2	SEAL BAR SUPPORT	2
14	-----	8	SPRING 9/32" Ø x 20	8
13	002-0197	2	SEAL BAR GUIDE FRONT	2
12	002-0240	2	SEAL BAR GUIDE REAR	2
11	001-1161	2	SPACER	2
10	008-0267	2	CUTTING BLADE	2
9	001-1160	2	BLADE SUPPORT	2
8	051-0310	4	BOLT 5/16" - 18 x 1 1/2"	4
7	001-1186	1	BEAM REIN. PLATE	1
6	002-0254	1	COVER	1
5	005-0287	1	CROSS BEAM ASSEMBLY	1
4	051-0760	4	FLAT WASHER 5/16"	4
3	051-0600	4	NUT 5/16" - 18	4
2	001-1187	1	CROSS BEAM COVER	1
1	058-0014	2	WIND DOWN CLIPS	2
				QTY

		DRUMMOND VILLE, QUEBEC, CANADA.	
TOLERANCE A : 5 B : 105 C : 1005 D : 1005 ANGLE : 5		DATE 90-08-29 DATE	
NOM MACHINE VACUUM 600		NE PAS MESURER	
NOM PIECE COVER ASSEMBLY MECHANICAL BAG CUT OPTION		RESUME ALAIN APPR.	
QTE.	ECH.	MATERIEL	005-0273




19	008-0276	RUBBER SEAL	2
18	-----	COVER GASKET	1
17	076--	O-RING 3/16" x 5/16"	5
16	056-0014	HOLD DOWN CLIP	2
15	051-0760	FLAT WASHER 5/16"	4
14	051-0150	BOLT #10-24 x 1 1/2"	1
13	051-0600	NUT 5/16" - 18	4
12	051-0310	BOLT 5/16" - 18 x 1 1/2	4
ITEM	# PIECE	DESCRIPTION	QTE

11	051-0160	SLOTTED SCREW #10-24x3"	4
10	051-0740	FLAT WASHER 1/4"	5
9	051-0570	ACORN NUT #10-24	5
8	002-0255	SEAL BAR SPACER	4
7	001-1187	CROSS BEAM COVER	1
6	005-0287	CROSS BEAM ASSEMBLY	1
ITEM	# PIECE	DESCRIPTION	QTE




5	001-1186	BEAM REINF. PLATE	1	QTE
4	001-0093	RUBBER SEAL HOLDER	2	
3	001-1182	SEAL BAR SUPPORT	2	
2	005-0286	GUIDE SUPPORT ASSEMBLY	1	
1	002-0254	COVER	1	
ITEM	# PIECE	DESCRIPTION		QTE


		DAINVILLE VILLE, QUEBEC, CANADA.	
TOLERANCE ± 1.5 ± 1.05 ± 1.005 ± 1.0005 ± 1.0001		NE PAS MESURER	
VACUUM 600 COVER ASSEMBLY		90-07-23	
1 MATERIAL		ALAIN DAVE	
1 MATERIAL		90-08-10	
1 MATERIAL		005-0272	




4 Impossible to program any timer (all of the display is on)	4.1 Programming error	Press "V", "G" or "S" to be in programming mode. Only 1 timer at a time.
	4.2 Defective PC board	Replace PC board
5 Impossible to program one timer (V,G, or S) (all of the display is on) (see step 4 first)	5.1 Defective membrane switch	Replace membrane switch
	5.2 Defective PC board	Replace PC board
6 PC board doesn't keep data in memory	6.1 Battery not charged	Run the machine or leave it plugged in with switch in off position for a few hours to charge battery.
	6.2 Defective battery	Replace battery or complete PC board (the battery is mounted on the PC board)
	6.3 Defective PC board	Replace PC board
7 Cycle doesn't start	7.1 Poorly adjusted cover Switch	Adjust
	7.2 Bad connection or defective limit switch	Verify
	7.3 Defective PC board	Replace PC board
	7.4 PC board is OK, outputs are defective (dwg #006-0029)	Check pump fuses, pump contactor coil, valves etc.



*ELECTRICAL DRAWING*




# WIRING OF 15 PINS "D" CONNECTOR ON SIPROMAC VACUUM PACKAGING MACHINE




## COLOR CODE

- |                   |             |   |
|-------------------|-------------|---|
|                   | 1- BLACK :  | OUTPUT TO ATMOSPHERE VALVE                            |
|                   | 2- WHITE :  | OUTPUT TO SEALING CONTACTOR                           |
|                   | 3- GREEN :  | OUTPUT TO GAZ VALVE                                   |
| PC BOARD<br>RELAY | 4- RED :    | CONTACT OF PC BOARD RELAY                             |
|                   | 5- BLACK :  | CONTACT OF PC BOARD RELAY ACTIVATE WHEN MACHINE IS ON |
|                   | 6- YELLOW:  | INPUT: 9 VOLTS +                                      |
|                   | 7- -----:   | JUMPED WITH # 6                                       |
| COVER<br>SWITCH   | 8- WHITE :  | TO COVER SWITCH                                       |
|                   | 10- RED :   | OUTPUT TO VACUUM VALVE                                |
|                   | 9- -----:   | NOT USED  |
|                   | 11- BLACK : | OUTPUT TO SEALING SELENOID VALVE                      |
|                   | 13- ORANGE: | INPUT: 9 VOLTS -                                      |
|                   | 14- -----:  | JUMPED WITH # 13                                      |
|                   | 12- BLACK : | INPUT 24 VAC  |
|                   | 15- BROWN : | TO COVER SWITCH                                       |

NOM MACHINE <b>VACUUM</b>		TOLERANCE 0. : .5 mm .0 : .01 mm .00 : .001 mm .000 : .0001 mm ANGLE : 0.30°		
NOM PIECE <b>WIRING DIAGRAM 15 PINS</b>				
QTE. _____	ECH. _____	FILIERE _____	OP. _____	DRUMMOND VILLE, QUEBEC, CANADA.
MATERIEL		DESSINE <b>DAVE A</b>	DATE <b>90-07-10</b>	NO DESSIN <b>006-0029</b>
		APPR. _____	DATE _____	





ALL CIRCLED NUMBER WIRES  
GO TO P.C. BOARD

**NON MACHIN**

VACUUM 600 ET 420

NON PICK

# ELECTRICAL WIRING Low Voltage.

111

111.

NE PAS MESURER

sub

89-01-24

**DAY 1**

TOLERANCE

0.15
0.05
0.005
0.0005




DRUMMOND VILLE, QUEBEC, CANADA.

MISSISSAUGA



89-01-24

006-0034



MOTOR	FLOW	Voltage + Phase	PHASE
3 HP	63 m <sup>3</sup>	230-1	MCL-30
5 HP	100 m <sup>3</sup>	230-1	MEV-25

Power



HOW MACHINE

VACUUM 600 ~ 10

HOW PIECE

ELECTRICAL wiring Hight Voltage

DATE

TECH.

MATERIAL

NE PAS MESURER

DESIGN

Y. M.

89-01-26


NO 0851M

006 - 0039


TOLERANCE  
± 1.5  
± 1.05  
± 1.005  
± 1.0005  
± 1.00005



DRUMMOND VILLE, QUEBEC, CANADA.







# PNEUMATIC DRAWING






ITEM	#	PIECE	DESCRIPTION	QT.
1	106-8262G22		GAS VALVE	2*
2			VACUUMETER	1
3A	106-8320G176		BELLOWS VALVE	1
3B	106-8320G176		BELLOWS VALVE	1*
4			PRESSURE REGULATOR	1*
5	106-8210G95		ATMOSPHERE VALVE FOR 420A	
	106-8210G95		ATMOSPHERE VALVE FOR 600A, 083M <sup>3</sup> AND 100 M <sup>3</sup>	
	106-8215B60		ATMOSPHERE VALVE FOR 600A & 620A: 160 M <sup>3</sup> AND 250 M <sup>3</sup>	1
	106-8215B60		ATMOSPHERE VALVE FOR 650A & 700A	
6	106-8210G95		VACUUM VALVE FOR 420A	
	106-8215B60		VACUUM VALVE FOR 600A & 620A	1
	106-8215B80		VACUUM VALVE FOR 650A & 700A	
*: OPTION				



MACHINE <b>420A, 600A, 620A &amp; 650A</b>		METRIC TOLERANCE 0.0 ± .015 0.0 ± .05 0.00 ± .005 0.00 ± .0005 ANGLE ± 1°		INCH TOLERANCE 0.0 ± .015 0.0 ± .05 0.00 ± .005 0.00 ± .0005		SIPROMAC ST-GERMAIN DE GRANTHAM QUEBEC CANADA	
PIECE <b>PNEUMATIC</b>		ECH. SCALE		NE PAS MESURER / N.T.S.		DATE 94-03-03	
QT.	ECH. SCALE		NE PAS MESURER / N.T.S.		DATE 94-03-03		NO.
MAT.	ECH. SCALE		NE PAS MESURER / N.T.S.		DATE 94-03-03		NO.
LET.	MODIFICATION		DATE		INT.		007-0019



**MODEL MACHINE**

VACUUM 600

HOW MUCH

## PNEUMATIC DRAWING

218.

СН.

NE

**MAYE RICH**

1000

ALAIN

A



DRUMMONDVILLE, QUEBEC, CANADA.


MISSO ON

90-08-23

007-0019



GAS



DRUMMONDVILLE, QUEBEC, CANADA.

TOLERANCE  
A 1.5  
B 1.05  
C 1.005  
D 1.005  
HOLE 1.1

VACUUM 600

PNEUMATIC DRAWING  
PRESSUR REGULATOR OPTION

NE PAS MESURER

DATE 90-08-23

NAME ALAIN

MATERIAL

SET TO A MAXIMUM OF 30 PSI

007 0020




1 of 1  
NEAL

Vacuum Panneau avant

450  
550  
600  
650

5 BLUE


#8 LIGHT



com 24V  
Polarity

8-12-85

711: SHCCLY 836 L150



MOTOR	FLOW	F1	Q1
3.6 HP, 8.4A	63 m <sup>3</sup> /h	15A	10A
5 HP, 13.6A	100 m <sup>3</sup> /h	20A	17A
7.5 HP, 22A	160 m <sup>3</sup> /h	30A	27.5A

NO: E-8	DATE: 6-10-07	DESCRIPTION
R1	VACUUM RETENTION METER	
R2	GAS RETENTION METER	
R3	SEALING RETENTION METER	
R4	BAG CUTTER, PCT. (OPTION)	
R5	BAG CUTTER ELEMENT (OPT.)	
R6	SEALING BAR ELEMENT	
L1-L2	SELENOID VALVE FOR GAS	
L3	SELENOID VALVE FOR SEALING	
L4	SELENOID VALVE FOR ATMOSPHERIC	
L5	SELENOID VALVE FOR VACUUM	
S1	CYCLE INTERRUPTION SWITCH	
S2	GAS INTERRUPTION SWITCH	
S3	MAIN SWITCH	
S4	POWER SWITCH (LEFT)	
S5	POWER SWITCH (RIGHT)	
MR1	MAGNETIC RELAY - MOTOR	
MR2	SEALING	
MR3	BAG CUTTER	
T1	MAIN TRANSFORMER (750 VA)	
T2	TRANSFORMER (32 VA)	
OLI	OVERLOAD	
M	3.6 HP MOTOR	
*	OPTIONAL	